



WC-101 Quick Start Guide

Rev. B

Important

- Failure to adhere to all the safety warnings in the manual may result in damage or injury
- This product is intended for indoor use only
- Remove all the protective film from the CLiC Glass prior to connecting the wiring to the WC-101
- Do not apply power to the WC-101 until all the wiring terminations are completed

Power/Signal Cable

- Red: +24VDC
- Black: Ground
- Blue/White: Status Out
- Purple: Dry Contact
- Green: Common



Output Cable

- Orange (x2): CLiC Glass Output (Polarity Not Important)

Before starting, verify that you have properly installed the building wiring according to the CLiC Glass Wiring Guide and local building codes, prior to connecting wires to the WC-101

Step 1: Remove Preserve Film from the CLiC Glass panel

Step 2: Verify wiring is terminated to the CLiC Glass panel

Step 3: Terminate WC-101 Output Cable to the CLiC Glass wiring

Step 4: Terminate User-Control to the Dry Contact and Common wires

Step 5: Connect Power Supply to the WC-101 Power Connector

Step 6: (Optional) For feedback of the glass state when using an automation system, connect the Status Out (+3.3VDC when clear, 0VDC when private) and Common wires to your system

For detailed instructions visit our website at www.clicglass.com



©2025 Cardinal Glass Industries